

Wallaby Assembly Instructions

Wallaby Sewing Cabinet

Congratulations on the purchase of your new Wallaby Sewing Cabinet. Every effort has been taken to ensure your complete satisfaction with this custom designed product. For your convienience the Wallaby Sewing Cabinet is supplied in three ready to assemble packs

*Accessories not included

Helpful Assembly Hints

Read the instructions carefully before starting. Check to see that all the parts are included. Work in a spacious area preferably on a carpet or soft surface. You will need a phillips head and flat head screw driver for the assembly. A cordless drill is preferable. Ensure the phillips head screwdriver fits neatly and fully engages the screw head. Failure to do this may result in screw damage. Make sure you tighten all the screws securely and tap dowels all the way in.

Warranty Information

G-day mate! We warranty our product for 5 years from date of shipment for manufacturer's defects or shipping damage within the first 15 days. The warranty does not cover damage caused by abuse, mis-use, alteration, accident, or neglect of the product. The warranty does not cover damage caused by moving the cabinet fully loaded. Under the terms of this warranty the repair and replacement of any parts shall be at the discretion of the company or their designated representative.

Replacement Part Shipping Policy

To help protect our valuable resources, we ship all replacement parts out at the same time. This procedure lessens the use of packaging materials and fossil fuels used in transportation keeping our world for all kangaroos and the people like you a cleaner place. Please help us in this endeavor by reviewing all parts in all boxes for damage before calling or e-mailing us to report damage. We adhere to our environmental philosophy by only shipping replacement parts out 1 time for free. Replacement parts are shipped free of charge only during the first year. Additional parts requests will be billed at the customer's expense.

Cabinet Care

Your Wallaby Sewing Cabinet normally requires a minimum amount of maintenance, however the following points are worth noting:

CLEANING - To remove marks and enhance the surface, wipe over with a general purpose cleaner.

CAUTION - Do not use ammonia based cleaning agents. Do not use harsh chemicals or abrasive cleaners. The surface can be wiped with a damp cloth but should be dried quickly.


If you have missing or damaged parts please call Kangaroo Kabinets at 1-800-533-7347 or email us a: cs@kangarookabinets.com

Also visit our website: www.kangarookabinets.com to view our Assembly Video


C	OMPONENTS	DESCRIPTION	QTY	
		Cam Bolt 24mm	12	
8		Cam (A) 15 x 15mm	10	
(x)		Screw (Silver) 5 x 57mm	6	
	- CP	Cover Cap	4	
		Dowel 8 x 30mm	28	
Α	ĝm>	Screw 3.4 x 15mm	94	
D	0	Screw 3.5 x 18mm	6	
Е		Screw 3 x 25mm	13	
F	ĝø.	Screw 6 x 10mm	4	
	©	Caster Washer	5	
	\$	Non-Locking Caster	5	
	B	- Locking Caster	3	
		Caster Bracket	3	
5/2		Caster Wrench	1	
(9)		Cam (B) 15 x 10mm	2	
2) xmmmm>		Screw (Brass) 4 x 32mm	4	
		Flap Hinge	3	
- C. C.		Butt Hinge	2	
\$		Flush Hinge	6	
		Drawer Runner*	1 Set	
		Bow Handle + Screws	2	
	5	Glue Bottle	2	
	Carrier State	Lock Striker	1	
		Equalizer	2	
(Lock & Key	1	

COMPONENTS	DESCRIPTION	QTY
	Insert Holder	1
-	Lifter Rail (Right)	1
	Lifter Rait (Left)	1
	Lifter	1
®	Support Leg Button	1
₹	Door Plate	2
Ø	Swivel Tray Bracket	2
	Door Shelf (Left)	1
	Door Shelf (Right)	1
	Large Bucket	1
	Swivel Tray	2
	Pin Cushion Foam	2
	Plastic Handle	1
	Stay Arm_	1
£	Stay Arm Bracket	1
	Lock Hole	1
	Ramp	3


^{*}Excludees pre-attached Drawer Runners on Drawer Sides




Page 3




Page 4




Page 5







Page 7




Page 8




Page 9




Page 10




Page 11




Page 12



Page 13




Page 14



Page 15

Operating Instructions

To open the Sewing Kabinet simply lift open the support leaves on the top. One opens to the right and is supported by the right, front door. The second leaf opens forward and is supported by the left, front door. Both of these leaves must be supported by the doors underneath if any pressure is to be placed on the leaves. The Quilt Leaf Extension on the back of the Kabinet folds upward and is supported by the support panel underneath. Opening the leaves without support from the doors can and will cause structural damage to the cabinet and your machinery as well as bodily harm to the user. If you have trouble with your doors being uneven, place a washer over the threaded peg of the caster between that and the door. This will raise the door up 1/8 inch.




How To Work the Air Lift Mechanism

The Air Lift has 3 positions for your sewing machine: storage, flatbed and freearm.

Follow these simple instructions to move the Air Lift into the 3 Different Positions:


- Once your cabinet is fully assembled you can begin moving the Air Lift
- 2) To activate the mechanism for the first time <u>open the door</u> on the cabinet and push down with 2 hands on the platform and release, as shown below in pictures 1 and 2.
- 3) The top position known as the freearm position usually takes 2 small pushes to activate. The freearm position has more resistance then the other two positions.
- Once you are comfortable moving the platform up and down into the 3 positions place your sewing machine on the platform.
- 5) Before moving the platform with your sewing machine on it, check to see that your machine is sitting centered on the platform and will not hit the sides of the cabinet as it moves up and down in the cabinet.
- 6) Push down on your sewing machine sitting in the cabinet to activate the Air Lift, as shown below in picture 3.
- 7) Heavier machines (20 pounds or more) may move slower then other lightweight machines and may need assistance as they move into the top positions. Heavier machines may require you to lift slightly on the platform for machine to lock the Air Lift into position.







Picture 2



Picture 3

How to Adjust the Airlift Mechanism

To Adjust the height of the airlift mechanism in the flatbed position you will need to gather the following: Automatic Drill w/ Phillips screw bit and two people. First position the airlift in the flatbed position. Loosen both screws on the Right Lifter Rail 1/4" to 1/2" as shown in, FIG 1 and 2 however DO NOT loosen the screws completely out of the Lifter Rail. Next place your machine on the platform with a straight edge, have the second person push the platform down to the right height so the straight edge is touching the table top as shown in FIG 3 and 4. Tighten both screws on the Right Lifter Rail completely. The flatbed position should now be the right height for ideal sewing. For a video of this please visit the FAQ section of our website www.kangarookabinets.com.

FIG 1 FIG 2





FIG 3 FIG 4



