


ASSEMBLY INSTRUCTIONS

Dixie

ITEM NO.: 3401 White



General Assembly Guidelines

1. Read the instructions carefully before beginning the assembly process to ensure proper assembly of this product. Please open and inspect the contents of box(es) to see that all parts and hardware are included.

2. Tools Required



Phillips Screwdriver 



Hammer



Electric Screwdriver 
Torque set to 3-5

Use and Care


Your cabinet normally requires a minimum amount of maintenance; however, it is worth noting the following for regular cleaning:

To remove marks and enhance the surface, wipe with a gentle all-purpose cleanser. DO NOT use ammonia-based, harsh chemicals or abrasive cleaning agents. Wipe dry immediately.

Parts List: Hardware



b1 6x12 Bolt **x12**



b2 8x25 Bolt **x10**




b3 4x8 Bolt **x2**




b4 6x35 Bolt **x18**




s1 3.5x14 Screw **x40**



b Bracket **x2**



p Plastic Support Tube **x2**



h1 Hinge **x6**




r1 4mm Allen wrench **x1**



r2 5mm Allen wrench **x1**

Parts List: Panels



ITEM	DESCRIPTION	QTY.	PACK.
A	Top panel	1	2 of 2
A1	Top leaf	2	2 of 2
F	Shelf	2	2 of 2
F1	Frame leg support	2	1 of 2
S	Side leg supports	2	1 of 2
L	Adjustable leg with casters	6	1 of 2
R	Rail	3	1 of 2


Part 1: Base



b1 6x12 Bolt **x12**



r1 4mm Allen wrench **x1**



Slide **Adjustable Legs (Part L)** into **Support (Part F1)**. Adjust to the same height on both legs for stability and secure with **b1 Fix Bolts**. Tighten with **r1 4mm Allen Wrench**.

Repeat with remaining L and F1 parts (2 assemblies total).

Slide in **Adjustable Leg (Part L)** into **Side Leg Support (Part S)**. Repeat with remaining **Part L** and **Part S** (2 assemblies total).

Adjust to the same height on both legs for stability and secure with **b1 Fix Bolts**. Tighten with **r1 4mm Allen Wrench**.


Part 1: Base



b2 8x25 Bolt **x6**




r2 5mm Allen wrench **x1**




Connect the two **Frame Leg Supports (Part F1)** with three **Rails (Part R)** using **b2 Bolts**.

TIP: Only partially tighten bolts with **r2 5mm Allen Wrench**. This will make the next step easier.

Part 1: Base



b2 8x25 Bolt x4



b4 6x35 Bolt x12




r2 5mm Allen wrench x1




r1 4mm Allen wrench x1

Connect the two **Side Leg Supports (Part S)** with **Leg Frame Assembly (Part F1)** using **b2 Bolts**. Tighten with **r2 5mm Allen Wrench**.



Place **Fixed Shelves (Panel F)** on the **Leg Frame Assembly (F1)** and attach using **b4 Bolts**. Tighten with **r1 4mm Allen Wrench**.


Part 2: Top



h1 Hinge **x6**



s1 3.5x14 Screw **x36**



Attach **Panels A1** to **Panel A** with **h1 Hinges** as shown. Position **h1 Hinges** in indentations on **Panels A1** and **A** and attach with **s1 Screws**.


Part 2: Top



b4 6x35 Bolt **x6**




r1 4mm Allen wrench **x1**




This step may require two people. Flip and align entire **Leg Assembly** with holes on **Panel A** and attach using **b4 Bolts**. Tighten with **r1 4mm Allen Wrench**.

Part 2: Top



b Bracket **x2**





p Plastic Support Tube **x2**



b3 4x8 Bolt **x2**


Attach **p Plastic Support Tube** to **b Connector** using **b3 Bolt** as shown.

Repeat with remaining Plastic Support Tube and Connector, two



Click **b/p Plastic Support Tube Assembly** onto **S Side Leg Assembly**, as shown.

Slide leg assembly with support tube over to pre-drilled hole on the underside of **Panel A1**.




Part 2: Top




s1 3.5x14 Screw **x4**

1.




Slide **S Support Leg** with **b/p Plastic Support Tube Assembly** to pre-drilled hole

2.




Align one hole with pre-drilled hole

3.




Attach with **s1 Screw**.

4.




Align the support leg the way you want it, and install a second **s1 Screw**. There is no pre-drilled hole, so you may have to apply extra pressure.

Part 2: Top




Two people may be required to flip the cutting table up onto its wheels.



Make sure all legs contact the ground and side leg supports are properly snapped into connectors on both sides before use.

Completed Dixie Cutting Table



Congratulations! A better sewing experience awaits!



LIMITED WARRANTY

Arrow Classic Sewing Furniture 10-Year Warranty

WHAT THIS WARRANTY COVERS: Arrow Companies, LLC (Arrow) provides limited warranty coverage to the original purchaser of this product against defects in materials or workmanship of Arrow furniture components for a period of ten years from the date of purchase. As used in this Warranty, "defect" means imperfections in components which substantially impair the utility of the product. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

HOW TO GET SERVICE: Simply contact Arrow at 1-800-533-7347 or CS@ArrowSewing.com. When you request warranty service, you must also present proof of purchase documentation, which includes the date of purchase (detailed receipt), and photos of the product. Arrow will replace any defective part (at its sole option), excluding labor. Replacement parts will be warranted for only the remaining period of the original Warranty.

Replacement parts will be shipped freight prepaid on any initial warranty claim during first year of Warranty only. Warranty applies only to defects confirmed by Arrow Companies, LLC and will be replaced or repaired at Arrow's option. In the event parts are no longer available for a warranty claim, customer may receive brand new cabinet at a price equal to 60% off the MSRP of a current comparable model.

WHAT'S NOT COVERED: There is no Warranty coverage for defects or conditions that result from the following: Failure to follow product assembly instructions, information or warnings; misuse or abuse; intentional damage; fire, flood, alteration or modification of the product; use of the product in a manner inconsistent with its intended use; any condition resulting from incorrect or inadequate maintenance, cleaning, care or neglect; cuts or scratches; caster damage as a result of moving furniture fully loaded or with locked casters; damage resulting from electrical surge or lightning; or use in commercial or education environments. Arrow Sewing Furniture is designed for residential use only.

ARROW SHALL HAVE NO LIABILITY for ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND and all such damages are EXCLUDED FROM THIS WARRANTY, such as loss of use, disassembly, transportation, labor or damage to property on or near the product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. The Warranty cannot be transferred to subsequent owners or users of the product, and it shall be immediately void in the event the product is resold, transferred, leased or rented to any third party or person other than the original purchaser.

ADDITIONAL LIMITATIONS: THERE ARE NO OTHER WARRANTIES APPLICABLE TO THIS PRODUCT. Under the laws of certain states, there may be no implied warranties from Arrow and all implied warranties, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE are disclaimed where allowed by law. TO THE EXTENT ANY IMPLIED WARRANTIES ARE APPLICABLE, ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY or the minimum period allowed by law, whichever is shorter. Some states do not allow limitations on how long an implied Warranty lasts, so the above limitation may not apply to you. This limited warranty gives you specific legal rights. This limited warranty does not, in any way, affect the rights given to you by law.


REGISTER YOUR PRODUCT: Original purchaser should register the purchase online at www.ArrowSewing.com/warranty.

COMPLETE YOUR SEWING STUDIO!

Elevate your sewing experience with Arrow's Best-Selling Accessories!

Custom Sewing Inserts


Enhance your sewing experience with a custom acrylic sewing insert! Custom acrylic sewing inserts are designed to fill the gap between your sewing machine and sewing cabinet's lift opening to create a flush, ergonomic surface for flat bed sewing. To ensure a perfect fit, custom acrylic sewing inserts are built specifically for your sewing machine and sewing cabinet combination. Say hello to happy wrists, straighter stitches, and an elevated sewing experience!



Custom Sewing Insert

Sewing Chairs

Arrow's #1 Rated Height Adjustable Sewing Chair is a must have accessory for your dream sewing room! Cute, comfortable and convenient - our lovable sewing chairs feature vibrant sewing themed patterns, 360° swivel access and lumbar support for long hours at your workstation. Don't look now, but under every seat cushion is a hidden storage compartment to store your notions and patterns! Available in 10 colors to perfectly match your sewing sanctuary!



Height Adjustable Sewing Chair